



The Shipping Store

Printer Margin Calibration Guide

1

Print this paper

2

Measure this line



If the line's measurement is not one inch, disable page scaling within your printer dialog box.

3

Find non-printable area

Match the first fully visible circle with its corresponding number to determine the non-printable area on each side

4

Adjust margins

Adjust margins based on your determined non-printable area from step 3.

